
**OPERATING INSTRUCTIONS: AVN 200
DVD INTERVIEW RECORDER**



**GUIDANCE/SET UP NOTES FOR THE
AVN 200 DVD INTERVIEW RECORDER**

The AVN 200 DVD Interview Recorder is to be used to make dual copy recordings of an interview onto 4.7 Gb DVD+R.

AV NICHE (RECORDING SYSTEMS) LIMITED

AV Niche House

5 Heron Court

Cranes Farm Road

Basildon

Essex

SS14 3DF

Tel: (01268) 474608

Fax: (01268) 531482

E-mail: avniche@btconnect.com

Web: www.avniche.co.uk

RECORDING

1. THE AVN 200 DVD INTERVIEW RECORDER CAN NOW BE SWITCHED ON BY THE ON / OFF BUTTON WHICH IS LOCATED ON THE BACK OF THE DVD RECORDER MODULE. THE LCD MESSAGE DISPLAY WILL DISPLAY THE MESSAGE "PLEASE WAIT...".




WHEN THE LCD MESSAGE DISPLAY SHOWS THE FOLLOWING MESSAGE: "PRESS EJECT TO INSERT NEW DVDS" THEN THE AVN 200 DVD INTERVIEW RECORDER IS READY TO BE USED.

To make a Recording

2. PRESS THE EJECT BUTTON TO OPEN THE TRAYS



3. PLACE 2 BLANK DVD+Rs INTO THE TRAYS (PRINTED SIDE UP) THEN PRESS THE EJECT BUTTON AGAIN AND THE DVD TRAYS WILL CLOSE



4. WAIT FOR THE SYSTEM TO PERFORM INITIAL CHECKS, THE MESSAGE "CHECKING DVDS..." WILL BE DISPLAYED (nb: if the DVDs are not blank, not inserted, already recorded or the wrong type; the system will reject the DVDs and you will need to replace the disc(s))



5. WAIT UNTIL THE ALARM SOUNDS WITH THE MESSAGE "READY TO RECORD", THEN PRESS THE RECORD BUTTON: THE EQUIPMENT WILL NOW START RECORDING.



To stop a Recording

6. PRESS AND HOLD THE STOP BUTTON UNTIL THE ALARM SOUNDS WITH THE MESSAGE "RECORDING STOPPED", THE RECORDING HAS FINISHED
(nb: an interview can be recorded for up to 1 hour 55 minutes and will stopped automatically when it reaches this duration. A "5 minute warning" alarm will sound at 1 hour 50 minutes to advise the user that the dvds will need changing.)



7. THEN THE MESSAGE "FINALIZING DVDS" WILL BE DISPLAYED INDICATING THAT THE DVDS HAVE ENTERED THEIR FINALISATION STAGE.
(nb: this will take a few minutes, be patient.)



8. THE TRAYS WILL EJECT THE DVDS AND THE MESSAGE "REMOVE DVDS AND PRESS EJECT" APPEARS. REMOVE THE RECORDED DVDS.



9. PRESS EJECT TO CLOSE THE TRAYS
(nb: if left open, the trays will automatically retract after a few minutes.)

After Operation

10. SWITCH OFF AT THE REAR OF THE UNIT

Nb: The recording equipment is supported by audio visual alarms and user prompts which will identify and describe any problems which may occur during the recording process.